

## HAND USE TRAY KIT FOR DYING EDGES

Hand use tray kit for dying edges. Materials: stainless steel, plastic.

This kit includes:

- Tray for the stain with roller and scraper
- Adjustable guide (height and width)
- Nonskid base



Dimensions: 250x70x80 mm

Weight: 840 gr

**Ref. 400-KTM-001**

If you are using several colours for dyeing, please consider using several stain trays, one for each colour. You will avoid waste of stain and loss of time while changing colour and cleaning the tray

January 2014

### Kit assembly:

Remove the cap from the tray and fill it with your dye until roller soaking in. Put the tray on the base, right on the clips to fix it. Turn the screw to adjust the scraper for a correct quantity of liquid on the roller. It will depends on the density of the dye you are using.

Put the guide on the base in order to fit it on the tray. The adjustment of the guide is made easy: two upper knurled knobs for the width and two lower knurled knobs for the height.

After use, remove the guide and replace the cap to avoid the dye to get dried before two applications.

### Maintenance:

Disassembly the tray and clean it at the end of every application. All parts of this kit are easily to clean. Wash it under warm water with a washing-up liquid.

### Attention:

Be careful of not to scratch the pieces with abrasive cleaning products or sponges.

---

Items are also available separately:



Adjustable guide  
Dimensions: 110 x 65 x 70mm  
Weight: 370 gr

**Ref. 400-GTM-001**



Nonskid base  
Dimensions: 240 x 65 x 10mm  
Weight: 240 gr

**Ref. 400-PTM-001**



Complete tray  
Dimensions: 110 x 65 x 70mm  
Weight: 230 gr

**Ref. 400-BTM-001**