

## HAND USE STAIN KIT

This kit has been developed to apply water-based (aqueous) dye with a manual applicator.

This applicator has an ergonomic rotary handle with removable sieves. These sieves have different forms and sizes depending on your need for different dyeing operations. The sieves can easily be exchanged.



Dimensions: 210 x 90 x 80 mm

Weight: 700 gr

**Ref. 400-KST-001**

The kit includes:

- 1 Stainless steel support for 2 plastic cups with incorporated rack (which can contain several sieves, to keep them handy at any time). Special location to place the handle pen.
- 1 rotary handle with two sieves ( $\varnothing 7 / 280\mu$  and  $\varnothing 9 / 280\mu$ )
- 2 rigid plastic cups: one for the dye (small depth) and the other for the water (big depth).
- 2 caps: one height to cover the ink, and the other one with an opening to receive the applicator pen in use.

January 2014



## Dyeing mode:

Put the full cap on the cup containing water and the opened cap on the cup containing your stain. Proceed to colour your pieces.

You can put down your applicator pen in the hollows of the full cap between two applications.



## When not it use:

Put the full cap covering the stain for not to dry and the cap with the opening on the container with the water. This way you can put your applicator dipping into the water.

## Recommendations:

- Use 2 or 3 sieves at the same time in order to keep them from clogging up too much.
- Always let the sieves soak in the water between two applications.
- Clean the sieves at the end of every use in order to extend their life span.
- Change the edge colouring regularly.
- Clean the cups before putting in fresh tint in order.
- Warning : do not scratch the inside of the cup.

## Maintenance:

All elements of the manual kit are easy to clean. Rinse them under warm water with a little washing-up liquid. You can also put it on the dish-washer.

## Range of colouring sieves

Ø2.5 mm, Ø5 mm/280µ,  
Ø7 mm/280µ, Ø9 mm/280µ,  
Ø9 mm/630µ, Ø9 mm/800µ

